



Steps to install and run the LabVIEW sample program:


- Requirement: LabView software, imager
- Download the Direct SDK free of charge from the Evocortex GmbH website:
<http://www.evocortex.org/downloads-1/>
- Connect the imager via USB to your PC
- Unzip the downloaded file *irDirectSDK-x_x_x*
- Open the folder and go to *irDirectSDK-x_x_x* → *irDirectSDK* → *bin* → *Win32* or *x64* (depends on the PC) and start *irDownloadCalibration* (The calibration files will be downloaded for the connected imager)




- Now go to *irDirectSDK-x_x_x* → *irDirectSDK* → *examples* → *labview* and open *libirimager_direct_binding*




- Open *example_usb.vi*




- Click on *Run*



- Push the button *Connect_usb* to connect the device with LabVIEW, in the field *w out* and *h out* the resolution of the imager is then shown



- By pressing the *get ThermallImage* button, the IR picture will be displayed in the window *Thermal Image*



Further settings:

terminate: Disconnects the camera

setAutoflag: 0 = autoflag off, 1 = autoflag on

triggerFlag: Flag is drawn